

iJust User Manual

Notice for Use

Thanks for choosing Eleaf product! Please read this manual carefully before use so that you can use it correctly. If you require more information or have questions about the product or its use, please consult your local agents, or visit our website at www.eleafworld.com.

Product Introduction

iJust, another new type of e-cigarette by Eleaf, features the brand new BDC atomizer head, the telescopic battery tube and the function of adjusting voltage. BDC atomizer enhances its effectiveness of vaporisation. The telescopic battery tube makes it fit into all batteries of 18-series. And the function of adjusting voltage brings you different experiences of puff-taking. Apart from these, its design and finish will also be a plus.

Standard configuration

- 2×iJust Mouthpiece
- 1×iJust Atomizer Tube
- 2×BDC Atomizer Head
- 1×iJust Atomizer Base
- 1×18650 Battery
- 1×iJust Battery Housing
- 1×iJust Drawtube
- 1×Battery Drive Pipe
- 1×Battery End Cap
- 1×iJust USB Cable
- 1×iJust Wall Charger
- 1×iJust User Manual


Quick Start

a) How to assemble:

Mount BDC atomizer head onto iJust atomizer base and then put together base, tube and mouthpiece. Second, put 18650 battery (or 18350 battery) into the battery tube. At last, assemble iJust battery and iJust atomizer.

b) How to use:

Quickly press the button five times to turn on iJust and turn it off in the same way. Keeping on pressing the button of iJust, take puffs at iJust. At the same time, user can adjust the voltage to his taste by turning the knob around the button. Additionally, one can put different batteries of 18-series into iJust battery tube through adjusting telescopic battery tube.



BDC atomizer head

BDC (bottom dual coil) atomizer head is introduced into Eleaf for the first time. It constitutes two coil (two kinds of resistance: 1.6 ohm and 1.8 ohm), a great deal enhancing the effectiveness of vaporisation and bringing you different experiences. BDC atomizer head ensures the large amount of vape under low voltage, no burning taste under high voltage and no leakage. Additionally, BDC atomizer head is similar to BBC atomizer head in size and appearance, so it is able to fit into Mini BCC, BCC Mega and iKit.

iJust Atomizer

The maximum capacity of iJust atomizer comes to 3.7ml. The detachable, washable and changeable atomizer head of new type enables carbon deposits on the filaments to be easily cleaned. It has a smooth air flow, no leakage, no burnt smell or taste.

iJust Power Supply

- Telescopic battery tube
- Colour: Space Gray


Properties of iJust battery

- a) High-safety, high-capacity, high-magnification and high-stability 18650 lithium battery.
- b) The battery adopts 3.7V constant voltage output, short circuit protection, over-charge and discharge protection, atomizer protection.
- c) Capacity: 2600 mAh

Usage of telescopic battery tube

To put 18350 battery into battery tube, take following steps:

- a) Take apart iJust battery housing from iJust drawtube;
- b) Pull drive pipe out of drawtube;
- c) Put 18350 battery into battery tube;
- d) Screw the drawtube onto the battery housing.



How to adjust voltage


One of obvious features of iJust is its function of adjusting voltage. The voltage range varies from 3.3 V to 4.8 V. Through turning around the knob either in right direction or in left direction, user can adjust its voltage to his taste.

How to charge

Plug the USB charger into its charging port on the battery tube. While it is being charged, the LED turns red till it is full and LED goes out.

How to add liquid

Unscrew iJust atomizer base out of iJust atomizer and then refill e-liquid into the atomizer. At last, Screw iJust atomizer base onto the iJust atomizer. (See Picture)



Attention:

- a) With less than 10% of e-liquid left in the tube, a slight burning taste may come out, which implies that you should refill it.
- b) In the process of using iJust, carbonisation and impurities will accumulate around the mouthpiece. For this reason, periodical clean and replacement of mouthpiece are necessary.

Precautions

- a) Have your iJust repaired only by Eleaf. Do not repair the unit by yourself as damage or personal injury may occur.
- b) Do not leave iJust in high temperature or damp condition, otherwise its performance may abate. The appropriate operation temperature is between 0 °C and 45 °C and the appropriate charging temperature between -10 °C and 60 °C.
- c) Do not assemble iJust with non-Eleaf parts. Any problem caused by this will invalidate your warranty and our company will not take on any responsibility.

Warranty

Please consult your Eleaf product warranty card. We are not responsible for any damages caused by human error. Our warranty is invalid for products purchased from third-party vendors.

Email: info@ismoka.com
Web: www.eleafworld.com



MADE IN CHINA
Manufactured by iSmoka